

REVISION HISTORY			VARIATIONS FOR THIS ASSY.		FIRST USED ON: M9312		DIGITAL EQUIPMENT CORPORATION MAYNARD, MASSACHUSETTS			
CHK	ECO NO	REV					TITLE			
					MADE BY: R CRAWM	DATE: 1 AUG 78	ROM LISTING DIAGNOSTIC			
					CHECKED: N POLLITT	DATE: 16 AUG 78				
					DSN.ENG.: R GIST	DATE: 1 AUG 78	SIZE	CODE	DOCUMENT NUMBER	REV
					PROD.: D PETERSON	DATE: 3 AUG 78	K	SP	M9312-0-5	B
					RESP.ENG.: E CROCKER	DATE: 1 AUG 78	ASSY. #:		EDIT NO:	
									1	
<p>"THIS DRAWING AND SPECIFICATIONS HEREIN, ARE THE PROPERTY OF DIGITAL EQUIPMENT CORPORATION AND SHALL NOT BE REPRODUCED OR COPIED OR USED IN WHOLE OR IN PART AS THE BASIS FOR THE MANUFACTURE OR SALE OF ITEMS WITHOUT WRITTEN PERMISSION. COPYRIGHT 1976. DIGITAL EQUIPMENT CORPORATION"</p>										

IDENTIFICATION

PRODUCT NAME ROM LISTING DIAGNOSTIC (K-SP-M9312-0-5)

SECTION 1 ROM 23-248F1---PAGE 3

SECTION 2 ROM 23-616F1---PAGE 31

DATE 1 AUG 1978

SECTION 1

ROM 23-248F1

TABLE OF CONTENTS

1.0	OPERATIONAL NOTES-----	PAGE 4
2.0	PRIMARY CPU DIAGNOSTICS-----	PAGE 15
3.0	CONSOLE FUNCTIONS-----	PAGE 18
4.0	TTY HANDLERS-----	PAGE 21
5.0	SECONDARY CPU DIAGNOSTICS-----	PAGE 25
6.0	MEMORY DIAGNOSTIC AND SIZE ROUTINES---	PAGE 28

1.0 OPERATIONAL NOTES

- 1.1. OVERVIEW
- 1.2. INTERNAL SWITCH SETTING
 - A. POWER UP AND CONSOLE BOOT SWITCHES
 - B. MICRO SWITCH SETTINGS
- 1.3. CONSOLE EMULATOR
- 1.4. BOOTSTRAPPING
- 1.5. DIAGNOSTIC TESTS
- 1.6. RESTARTING AT THE USER POWER FAIL ROUTINE
- 1.7. LOAD ADDRESS AND START PROCEDURE

1.0 OPERATIONAL NOTES

1.1. OVERVIEW

THE M9312 IS DESIGNED TO PROVIDE BOOTSTRAPPING CAPABILITIES FOR ALL PDP-11 SYSTEMS WITH OR WITHOUT THE CONSOLE SWITCH REGISTER. IN ADDITION TO PROVIDING BOOTSTRAPPING FUNCTIONS FOR ALL MAJOR PDP-11 DEVICES, THE M9312 INCLUDES ROUTINES FOR CONSOLE EMULATION AND ALSO PROVIDES SOME BASIC CPU AND MEMORY GO-NOGO DIAGNOSTIC TESTS.

THIS BOOTSTRAP HAS BEEN DESIGNED FOR MAXIMUM FLEXIBILITY OF OPERATION. ITS FUNCTIONS MAY BE INITIATED AUTOMATICALLY AT A POWER UP, OR BY DEPRESSING THE CONSOLE BOOT SWITCH, OR BY A LOAD ADDRESS AND START SEQUENCE, OR EVEN BY USING THE CONSOLE TTY WHILE RUNNING THE CONSOLE EMULATOR.

1.2. INTERNAL SWITCH SETTING

A SET OF EIGHT MICRO SWITCHES ARE LOCATED ON THE M9312 MODULE. THESE ARE USED BY THE ROUTINES TO DETERMINE WHAT ACTION IS TO BE TAKEN. THEY GIVE THE USER AUTOMATIC ACCESS TO ANY FUNCTION.

A. POWER UP AND CONSOLE BOOT SWITCHES

THE PRIMARY ACTIVATING PROCESSES FOR THE M9312 PROGRAMS ARE EITHER A POWER UP SEQUENCE OR THE ENABLING OF THE CONSOLE BOOT SWITCH.

TO ACTIVATE THE M9312 ON A POWER UP, SWITCH 2 IN THE M9312 MICRO SWITCH REGISTER MUST BE IN THE ON POSITION. IF THIS SWITCH IS OFF THEN A NORMAL TRAP TO LOCATION 24 TO EXECUTE THE USER POWER UP ROUTINE WILL OCCUR. WHEN THIS SWITCH IS ON THE OTHER SWITCHES, 3 THROUGH 10, WILL DETERMINE WHAT ACTION THE M9312 WILL TAKE WHEN THE POWER UP OCCURS (SEE MICRO SWITCH SETTING BELOW).

IF THE SYSTEM INCLUDES A CONSOLE BOOT SWITCH THEN ANY TIME THAT SWITCH IS PRESSED THE M9312 WILL BE ACTIVATED (SOME PROCESSORS MAY HAVE TO BE HALTED FOR THIS SWITCH TO HAVE ANY EFFECT). THE PROCESS USED TO ENTER THE ROM IS A "FAKE" POWER DOWN FOLLOWED BY A POWER UP CAUSED BY PRESSING THE BOOT SWITCH (NOTE THAT THE POSITION OF MICRO SWITCH 2 DESCRIBED ABOVE IS IRRELEVANT TO THE OPERATION OF THIS BOOT SWITCH). THIS RESULTS IN A NORMAL POWER UP SEQUENCE IN THE CPU. PRIOR TO THE POWER UP SEQUENCE, THE M9312 ASSERTS 773000 ON THE UNIBUS ADDRESS LINES. THIS CAUSES THE NEW PC TO BE TAKEN FROM ROM LOCATION 773024 INSTEAD OF FROM LOCATION 000024. THE NEW PC WILL BE THE LOGICAL 'OR' OF THE CONTENTS OF ROM LOCATION 773024 AND THE EIGHT MICRO SWITCHES ON THE M9312 MODULE (A SWITCH IN THE ON POSITION IS SEEN AS A ONE; LIKEWISE A SWITCH IN THE OFF POSITION IS A ZERO).

IN THIS WAY ALL THE M9312 OPTIONS ARE ACCESSABLE BY MERELY GIVING EACH OPTION A DIFFERENT STARTING ADDRESS. NOTE HERE THAT MICRO SWITCH NUMBER 10 IS OR'ED WITH BIT 1 OF THE DATA IN ROM LOCATION 773024, MICRO SWITCH NUMBER NINE IS OR'ED WITH BIT 2 ETC., AND THAT IT IS UNNECESSARY TO PROVIDE A SWITCH WHICH IS OR'ED WITH DATA BIT 0 AS THIS COULD RESULT IN AN ODD ADDRESS WHEN GOING THROUGH THE TRAP TO LOCATION 773024 SEQUENCE.

B. THE MICRO SWITCH SETTINGS.

THE SETTING OF THE MICRO SWITCHS DEPENDS ON THE VARIOUS ROMS USED AND THE POSITION THEY ARE USED IN ON THE M9312.

1.3. CONSOLE EMULATOR

THESE ROUTINES ARE ESSENTIAL TO ANY PROCESSOR WITHOUT A CONSOLE. THEY PROVIDE THE USER THE CONSOLE FUNCTIONS OF LOAD ADDRESS, EXAMINE, DEPOSIT, AND START. ALSO THE ABILITY TO EXECUTE A BOOTSTRAP FUNCTION WITH ANY OF THE ABOVE DEVICES IS GIVEN.

THE FIRST THING THAT WILL EXECUTED (IF 020 IS THE CONTENTS OF THE MICRO SWITCHES) ARE THE PRIMARY CPU DIAGNOSTICS.

THEN THE DISPLAY ROUTINE IS ENTERED. THIS ROUTINE TYPE THE CONTENTS OF R0, R4, SP AND R5 (NOTE THE SEQUENCE!) ON THE TELETYPE AS FOUR 16 BIT OCTAL NUMBERS. PRESSING THE CONSOLE BOOT SWITCH CAUSES PDP-11 SYSTEMS (E.G. PDP-11/04'S) WITHOUT CONSOLE SWITCH REGISTERS TO COPY THE PC INTO R5 BEFORE THE POWER UP SEQUENCE STARTS.

A KEYBOARD DISPATCH ROUTINE IS THEN ENTERED TO INTERPRETE THE USERS COMMANDS. THIS ROUTINE TYPES A CARRIAGE RETURN AND A LINE FEED, THEN GIVES THE PROMPT '@'. ALL COMMANDS ARE TWO CHARACTERS. IF THE USER TYPES AN ILLEGAL COMMAND IT WILL BE IGNORED AND THE KEYBOARD DISPATCH IS RESTARTED. LEGAL COMMANDS ARE:

L<SPC>NUMBER

LOAD ADDRESS::LOAD THE INTERNAL ADDRESS POINTER WITH 'NUMBER', A 16 BIT OCTAL NUMBER.

E<SPC>

EXAMINE::EXAMINE AND DISPLAY ON THE TELETYPE THE ADDRESS AND THE CONTENTS OF THAT ADDRESS IN THE INTERNAL ADDRESS POINTER (SEE LOAD ADDRESS). NOTE THAT IF THE PREVIOUS COMMAND WAS ALSO AN EXAMINE COMMAND THEN THE INTERNAL ADDRESS POINTER IS INCREMENTED BY 2.

D<SPC>

DEPOSIT::DEPOSIT THE VALUE NUMBER INTO THE LOCATION POINTED TO BY THE INTERNAL ADDRESS POINTER (SEE LOAD ADDRESS). IF THE PREVIOUS COMMAND WAS ALSO DEPOSIT THEN THE POINTER IS INCREMENTED BY 2.

S<CR>

START::CAUSES A RESET INSTRUCTION TO BE EXECUTED AND A JMP TO THE LOCATION SPECIFIED IN THE INTERNAL ADDRESS POINTER.

DP#
BOOT RP02 OR RP03::LOAD AND EXECUTE
THE MONITOR FROM THE DEVICE USING
THE DRIVE NUMBER OPTIONALLY
SPECIFIED BY # (DEFAULT 0) WITH OR
WITHOUT FIRST RUNNING SECONDARY CPU
AND MEMORY DIAGNOSTICS.

DB#
BOOT RP04/5/6 OR RM02/3::LOAD AND
EXECUTE THE MONITOR FROM THE DEVICE
USING THE DRIVE NUMBER OPTIONALLY
SPECIFIED BY # (DEFAULT 0) WITH OR
WITHOUT FIRST RUNNING SECONDARY CPU
AND MEMORY DIAGNOSTICS.

DS#
BOOT RS03 OR RS04::LOAD AND EXECUTE
THE MONITOR FROM THE DEVICE USING
THE DRIVE NUMBER OPTIONALLY
SPECIFIED BY # (DEFAULT 0) WITH OR
WITHOUT FIRST RUNNING SECONDARY CPU
AND MEMORY DIAGNOSTICS.

DK#
BOOT RK05 RK03/RK05J::LOAD AND
EXECUTE THE MONITOR FROM THE DEVICE
USING THE DRIVE NUMBER OPTIONALLY
SPECIFIED BY # (DEFAULT 0) WITH OR
WITHOUT FIRST RUNNING SECONDARY
CPU AND MEMORY DIAGNOSTICS.

DM#
BOOT RK06/RK07:LOAD AND EXECUTE THE
MONITOR FROM THE DEVICE USING THE
DRIVE NUMBER OPTIONALLY SPECIFIED BY
(DEFAULT 0) WITH OR WITHOUT FIRST
RUNNING SECONDARY CPU AND MEMORY
DIAGNOSTICS.

DX#
BOOT RX01::LOAD AND EXECUTE THE
MONITOR FROM THE DEVICE USING THE
DRIVE NUMBER OPTIONALLY SPECIFIED BY
WHICH MUST BE 0 OR 1 (DEFAULT 0)
WITH OR WITHOUT FIRST RUNNING
SECONDARY CPU AND MEMORY
DIAGNOSTICS.

DT#
BOOT TU56/TU55
LOAD AND EXECUTE THE
MONITOR FROM THE DEVICE USING THE
DRIVE NUMBER OPTIONALLY SPECIFIED BY
(DEFAULT 0) WITH OR WITHOUT FIRST
RUNNING SECONDARY CPU AND MEMORY
DIAGNOSTICS.

DY#
BOOT RX02::LOAD AND START THE
MONITOR FROM THE DEVICE USING THE
DRIVE NUMBER OPTIONALLY SPECIFIED BY
(DEFAULT 0) WITH OR WITHOUT FIRST
RUNNING SECONDARY CPU AND MEMORY
DIAGNOSTICS.

MT#
BOOT TU10 TE10,TS03
LOAD AND EXECUTE THE
MONITOR FROM THE DEVICE USING THE
DRIVE NUMBER OPTIONALLY SPECIFIED BY
(DEFAULT 0) WITH OR WITHOUT FIRST
RUNNING SECONDARY CPU AND MEMORY
DIAGNOSTICS.

MM#
BOOT TU16,TE16,TM02/3::
LOAD AND EXECUTE THE
MONITOR FROM THE DEVICE USING THE
DRIVE NUMBER OPTIONALLY SPECIFIED BY
(DEFAULT 0) WITH OR WITHOUT FIRST
SECONDARY CPU AND MEMORY
DIAGNOSTICS.

TT
BOOT DL11::READ THE ABSOLUTE PAPER
TAPE LOADER FROM THE TELETYPE PAPER
TAPE READER WITH OR WITHOUT FIRST
RUNNING THE SECONDARY CPU AND MEMORY
DIAGNOSTICS.

PR
BOOT PC11::READ THE ABSOLUTE PAPER
TAPE LOADER FROM THE HIGH SPEED
PAPER TAPE READER WITH OR WITHOUT
FIRST EXECUTING SECONDARY CPU AND
MEMORY DIAGNOSTICS.

DL#

BOOT RL11/RL01
LOAD AND EXECUTE THE
MONITOR FROM THE DEVICE USING THE
DRIVE NUMBER OPTIONALLY SPECIFIED BY
(DEFAULT 0) WITH OR WITHOUT FIRST
RUNNING SECONDARY CPU AND MEMORY
DIAGNOSTICS.

CT#

BOOT TU60:: LOAD AND EXECUTE THE
MONITOR FROM THE DEVICE USING
THE DRIVE NUMBER OPTIONALLY
SPECIFIED BY # (DEFAULT 0) WITH OR
WITHOUT CPU AND MEMORY DIAGNOSTICS.

NOTE:: MORE DEVICES MAY BE ADDED AFTER THIS
DOCUMENT IS RELEASED. THE INSTALLATION
DOCUMENT(K-SP-M9312-0-4)WILL BE UPDATED
AFTER EACH NEW ROM FOR A DEVICE WRITTEN
YOU MAY REFERENCE THAT DOCUMENT.

ALSO THE DIAGNOSTIC FOR THE M9312 WILL
TYPE OUT ALL NUMONICS WITHIN THE M9312.

1.4. BOOTSTRAPPING

THESE ROUTINES TO BOOTSTRAP A DEVICE TYPICALLY READ IN THE FIRST SECTOR, BLOCK OR 512 (DEC) WORDS, OFF THE DEVICE INTO LOCATION 0 THROUGH 512 (DEC) OF MEMORY. THE EXCEPTIONS TO THIS RULE ARE THE PAPER TAPE BOOT, THE FLEXIBLE DISK BOOT AND THE MAGNETIC TAPE BOOTS. THE PAPER TAPE BOOT IS UNIQUE IN THAT IT CAN DO NO ERROR CHECKING AND THAT THE SECONDARY BOOTSTRAP (THE ABSOLUTE LOADER, FOR EXAMPLE) IS READ INTO THE UPPER PART OF MEMORY. THE ACTUAL LOCATION LOADED BY THE PAPER TAPE BOOT ARE PARTIALLY DETERMINED BY THE SECONDARY BOOTSTRAP ITSELF AND BY THE 'SIZE' ROUTINE WHICH DETERMINES THE HIGHEST AVAILABLE MEMORY ADDRESS WITHIN THE FIRST 28K. THE FLEXIBLE DISK (OR FLOPPY) READS SECTOR 1 ON TRACK 1 INTO LOCATIONS STARTING AT ZERO. THE MAGNETIC TAPE BOOTS READ THE SECOND BLOCK INTO LOCATIONS STARTING AT 0. IF NO ERRORS ARE DETECTED IN THE DEVICE, THE BOOTSTRAPS NORMALLY TRANSFER CONTROL TO LOCATION 0 IN ORDER TO EXECUTE THE SECONDARY BOOTSTRAP JUST LOADED. THE ONLY EXCEPTION TO THIS STARTING ADDRESS IS WITH THE PAPER TAPE BOOTS. THEY TRANSFER CONTROL TO LOCATION XXX374, WHERE XXX WAS DETERMINED INITIALLY BY THE SIZE ROUTINE TO BE AT THE TOP OF MEMORY; THIS IS WHERE THE ABSOLUTE LOADER WAS JUST LOADED.

IF A DEVICE ERROR IS DETECTED A RESET WILL BE EXECUTED AND THE BOOTSTRAP WILL TRY AGAIN. THE BOOTSTRAP WILL BE RETRIED INDEFINITELY UNTIL IT SUCCEEDS WITHOUT ERROR UNLESS THE USERS (OPERATOR) INTERVENES. THE ADVANTAGE OF RETRYING THE BOOT IS THAT IF A PARTICULAR DEVICE BEING BOOTED IS NOT ONLINE OR LOADED, SAY BECAUSE OF A POWER FAILURE RESTART, THE BOOT WILL GIVE THE DEVICE A CHANCE TO POWER UP (FOR DISKS THIS IS ESSENTIAL). A MAGNETIC TAPE TRANSPORT WILL NOT AUTOMATICALLY RELOAD ITSELF AFTER A POWER FAILURE AND RESTART. THIS SITUATION REQUIRES USER INTERVENTION. THE USER MUST RELOAD THE MAGTAPE AND BRING IT BACK ONLINE AT WHICH TIME THE MAGTAPE BOOTSTRAP, WHICH WAS CONTINUALLY ATTEMPTING TO BOOT THE TAPE, WILL SUCCEED.

NOTE:: AN EXCEPTION TO THIS RULE ARE DEVICE BOOTS FOR THE RK06/RK07 AND RX02.

IN THE CASE OF THE RK06, IF A DRIVE TYPE ERROR IS ENCOUNTERED, THE DRIVE IS SET TO AN RK07.

IN THE CASE OF AN RX02, FIRST DOUBLE DENSITY IS TRYED, SOULD WE GET A DENSITY ERROR ON READ TRY, WE CHANGE THE DENSITY TO SINGLE DENSITY. IN EITHER CASE, WE READ TWO (2) SECTORS OF DATA.

SOME BOOTS ALLOW POWER-UP OR BOOT SWITCH BOOTING FOR DRIVES OTHER THAN DRIVE 0. REFER TO INDIVIDUAL BOOTS FOR THIS INFORMATION.

1.5. DIAGNOSTIC TESTS

THERE ARE THREE DIFFERENT TYPES OF TESTS INCLUDED IN THE M9312 :

- 1 PRIMARY CPU TESTS
- 2 SECONDARY CPU TESTS
- 3 MEMORY TEST

THE PRIMARY CPU TESTS ARE TESTS OF ALL UNARY AND DOUBLE OPERAND INSTRUCTIONS WITH ALL SOURCE MODES. THESE TESTS DO NOT MODIFY MEMORY. IF A FAILURE IS DETECTED A BRANCH DOT WILL BE EXECUTED.

THE SECONDARY CPU TESTS MODIFY MEMORY AND INVOLVE THE USE OF THE STACK POINTER. THESE TESTS INCLUDE TESTING OF THE JMP AND JSR INSTRUCTIONS AS WELL AS TESTS OF ALL DESTINATION MODES. IF A FAILURE IS DETECTED THESE TESTS, UNLIKE THE PRIMARY TESTS, WILL EXECUTE A HALT. THE USER MAY THEN CONSULT THIS LISTING TO DETERMINE THE FAULT CLASS FOR THE PARTICULAR LOCATION THE TEST HALTED.

FINALLY THE MEMORY TEST PERFORMS BOTH A DUAL ADDRESSING AND DATA CHECK OF ALL THE AVAILABLE MEMORY ON THE SYSTEM LESS THAN 28K. THIS TEST WILL LEAVE ALL OF MEMORY CLEAR. LIKE THE SECONDARY TESTS THE MEMORY TEST WILL HALT WHEN AN ERROR IS DETECTED. AT THE TIME THE MEMORY ERROR HALT IS EXECUTED R0 WILL CONTAIN THE ADDRESS AT WHICH THE FAILURE WAS DETECTED PLUS TWO! R4 WILL CONTAIN THE FAILING DATA PATTERN AND R6 WILL CONTAIN THE EXPECTED DATA PATTERN. THUS AFTER A MEMORY FAILURE HAS OCCURRED THE USER CAN ENTER THE CONSOLE EMULATOR AND HAVE THIS INFORMATION PRINTED OUT TO HIM IMMEDIATELY BY THE DISPLY ROUTINE (SEE ABOVE SECTION ON CONSOLE EMULATOR).

NOTE: HERE THAT DIAGNOSTICS ARE RUN OR NOT RUN (OPTIONALLY) DEPENDING ON WHETHER BIT 1 IS CLEAR OR SET (RESPECTIVELY) IN EITHER:

- 1 THE INTERNAL MICRO SWITCHES DESCRIBED ABOVE (IF THE POWER UP OR CONSOLE BOOT SWITCH METHOD IS USED); OR
- 2 THE CONSOLE SWITCH REGISTER (IF THE LOAD ADDRESS AND START WITH OPTION CODE IN SWITCHES METHOD DESCRIBED BELOW IS USED).

1.6. RESTARTING AT THE USER POWER FAIL ROUTINE

IF THE USER WISHES TO RESTART HIS OWN SOFTWARE ON A POWER UP HE MAY DO SO BY MERELY DISABLING THE POWER FAIL RESTART SWITCH IN THE MICRO SWITCHES (TURN SWITCH 2 OFF).

BUT THE USER CAN USE THE M9312 TO RUN DIAGNOSTICS (JUST THE PRIMARY CPU TESTS DESCRIBED ABOVE) BEFORE RUNNING HIS POWER UP ROUTINE. THIS WILL IN NO WAY DISTURB THE CONTENTS OF MEMORY AND WILL IN FACT VERIFY THE MACHINE'S BASIC INTEGRITY AFTER THE POWER DOWN AND UP SEQUENCE.

TO USE THIS OPTION PUT THE CODE 644 INTO THE MICRO SWITCHES AS DESCRIBED ABOVE. ALSO SWITCH 2 MUST BE OFF. THIS WILL RESULT IN THE RUNNING OF THE PRIMARY CPU DIAGNOSTICS AND THEN A SIMULATED TRAP THROUGH 24 WHICH WILL START THE USER'S SPECIFIED POWER UP ROUTINE.

IF THE CODE 646 IS PLACED IN THE INTERNAL SWITCHES THEN THE SIMULATED TRAP THROUGH 24 IS EXECUTED WITHOUT RUNNING ANY DIAGNOSTICS.

1.7. LOAD ADDRESS AND START PROCEDURE

ASCII CONSOLE AND DIAGNOSTIC ROM FOR USE WITH 11/04/05/10/20/34/35/40/45/50/55

FUNCTION TO BE	ROM	DIAG-	MANUAL
BOOTED	LOC.	INOSTIC	STARTING ADDR.
CONSOLE EMULATOR!	E20	NO	165144
CONSOLE EMULATOR!	E20	YES	165020

THE CONSOLE EMULATOR CAN PERFORM THE FOLLOWING FUNCTIONS:

- 1. LOAD ADDRESS
- 2. EXAMINE
- 3. DEPOSIT
- 4. START
- 5. BOOT A DEVICE

THE EXAMPLE BELOW CONTAINS THE START ADDRESS FOR EACH OF THE 4 ROM LOCATIONS REFERENCE THE INSTALLATION AND SET UP PROCEDURE (K-SP-M9312-0-4)FOR A COMPLETE LISTING

DEVICE TO BE	ROM	DIAG-	UNIT	START
BOOTED	LOC.	INOSTIC		ADDR.
RL01	ROM 1	NO	0	173004
RL01	ROM 1	YES	0	173006
RL01	ROM 2	NO	0	173204
RL01	ROM 2	YES	0	173206
RL01	ROM 3	NO	0	173404
RL01	ROM 3	YES	0	173406
RL01	ROM 4	NO	0	173604
RL01	ROM 4	YES	0	173606

2.0 PRIMARY CPU DIAGNOSTICS

2.1 COMMON DATA TABLE

2.2 TEST 1 SINGLE OPERAND INSTRUCTIONS

2.3 TEST 2 DOUBLEOPERAND INSTRUCTIONS, ALL SOURCE MODES, DEST MODE 0

2.4 TEST 3 JMP TEST MODES 1,2AND 3

2.5 TEST 4 SINGLE OPERAND, NON-MODIFYING INSTRUCTION, BYTE REFERENCING TEST

2.1 THIS IS A TABLE OF DATA USED IN BOTH THE PRIMARY AND THE SECONDARY CPU DIAGNOSTICS.

165000	165000	P00L:	.WORD	P00L
165002	165000		.WORD	P00L
165004	100000	T4DATA:	.WORD	100000
165006	177777	T6DATA:	.WORD	177777
165010	165006		.WORD	T6DATA
165012	165006		.WORD	T6DATA
165014	000500	T6DAT1:	.WORD	500
165015	000501		.WORD	501

2.2 ***** TEST 1 SINGLE OPERAND INSTRUCTIONS *****

165020	005003	TEST1:	CLR	R3	:	000000	0100
165022	005203		INC	R3	:	000001	0000
165024	005103		COM	R3	:	177776	1001
165026	006203		ASR	R3	:	177777	1010
165030	006303		ASL	R3	:	177776	1001
165032	006003		ROR	R3	:	177777	1010
165034	005703		TST	R3	:	177777	1000
165036	005403		NEG	R3	:	000001	0001
165040	005303		DEC	R3	:	000000	0101
165042	005603		SBC	R3	:	177777	1001
165044	006103		ROL	R3	:	177777	1001
165046	005503		ADC	R3	:	000000	0101
165050	000303		SWAB	R3	:	000000	0100
165052	001377		BNE	.	:		

;ERROR IF NOT ZERO.

2.3 ***** TEST 2 DOUBLE OPERAND INSTRUCTIONS, ALL SOURCE MODES, DEST MODE 0. *****

165054	012702	165000	TEST2:	MOV	#P00L,R2	;SET UP ADDRESS.
165060	011203			MOV	(R2),R3	;MOVE FROM TABLE DEFERRED.
165062	022203			CMP	(R2)+,R3	;CHECK FOR CORRECT DATA.
165064	001377			BNE	.	;LOOP HERE IF NOT EQUAL.
165066	063203			ADD	@(R2)+,R3	;ADD TO REGISTER.
165070	165203			SUB	@-(R2),R3	;SUBTRACT SAME DATA FROM REGISTER.
165072	044203			BIC	-(R2),R3	;SHOULD CLEAR REGISTER.
165074	056203	000012		BIS	12(R2),R3	;SHOULD SET ALL REGISTER'S BITS.
165100	037203	000012		BIT	@12(R2),R3	;SHOULD TEST NOT ZERO (Z=0).
165104	001777			BEQ	.	;LOOP HERE ON ERROR.

2.4 ***** TEST 3 JMP TEST MODES 1, 2 AND 3. *****

165106	010703		TEST3:	MOV	PC,R3	;SET UP ADDRESS FOR MODE 1 JMP.
165110	000123		JMP1:	JMP	(R3)+	;EXECUTE JMP MODE 2.
165112	012703	165122		MOV	#JMP2A,R3	;SET UP ADDRESS OF ADDRESS FOR MODE 3 JMP.
165116	000133			JMP	@(R3)+	;EXECUTE JMP MODE 3.
165120	000113		JMP2:	JMP	(R3)	;EXECUTE MODE 1 JMP TO NEXT TEST.
165122	165120		JMP2A:	.WORD	JMP2	

2.5 ***** TEST 4 SINGLE OPERAND, NON-MODIFYING INSTRUCTION, BYTE REFERENCING TEST. *****

165124	105767	177654	TEST4:	TSTB	T4DATA	:TEST EVEN BYTE.
165130	001377			BNE	.	:LOOP ON ERROR, NOT ZERO.
165132	022222			CMP	(R2)+,(R2)+	:GET ADDRESS OF T4DATA IN R2.
165134	105722			TSTB	(R2)+	:EXAMINE DATA USING MODE 2.
165136	001377			BNE	.	:LOOP IF NOT ZERO.
165140	105712			TSTB	(R2)	:TST ODD BYTE MODE 1.
165142	100377			RPL	.	:LOOP IF POSITIVE.

3.0 CONSOLE FUNCTIONS

3.1 DISPLAY

3.2 START

3.3 DEPOSIT

3.4 LOAD ADDRESS

3.5 EXAINE

3.0 CONSOLE FUNCTIONS

3.1 ***** DISPLAY *****

165144	010701		DSPLY:	MOV	PC,R1	
165146	000554			BR	PUTCR	;PRINT CR, LF AND FILLER CHARACTERS.
165150	010701			MOV	PC,R1	
165152	000526			BR	PUTNUM	;PRINT R0.
165154	010400			MOV	R4,R0	
165156	000524			BR	PUTNUM	;PRINT R4.
165160	010600		OUT:	MOV	SP,R0	
165162	010701			MOV	PC,R1	
165164	000521			BR	PUTNUM	;PRINT R6.
165166	010500			MOV	R5,R0	
165170	000517			BR	PUTNUM	;PRINT R5.
165172	010605			MOV	SP,R5	
165174	010701		CONSEM:	MOV	PC,R1	
165176	000540			BR	PUTCR	;PRINT CR, LF AND FILLER CHARACTERS.
165200	112702	000100		MOVB	#100,R2	;44 (OCTAL) IS THE ASCII FOR 'S', THE
165204	010703			MOV	PC,R3	;COMMAND PROMPT CHARACTER.
165206	000554			BR	PUTCHR	
165210	010706		READ:	MOV	PC,SP	
165212	000544			BR	GETCHR	;GET THE FIRST CHARACTER OF A COMMAND.
165214	000302			SWAB	R2	
165216	000542			BR	GETCHR	;GET THE SECOND CHARACTER OF THE COMMAND.
165220	020227			CMP	R2,(PC)+	;LOAD ADDR. INSTRUCTION?
165222	046040			.ASCII	" L"	
165224	001450			BEQ	LA	
165226	020402			CMP	R4,R2	;EQUALS LAST COMMAND?
165230	001001			RNE	1\$;NO SKIP.
165232	005725			TST	(5)+	;YES-UPDATE ADDR. POINTER.
165234	010204		1\$:	MOV	R2,R4	;RECORD THIS COMMAND.
165236	020227			CMP	R2,(PC)+	;IS CMMD A EXAM?
165240	042440			.ASCII	' E'	
165242	001446			BEQ	EX	;IF SO DO EXAM FUNCTION.
165244	020227			CMP	R2,(PC)+	;IS CMMD A DEPOSITE?
165246	042040			.ASCII	' D'	
165250	001432			BEQ	DE	;IF SO DO DEPOSITE FUNCTION.
165252	020227			CMP	R2,(PC)+	;IS IT A START COMMAND?
165254	051415			.ASCII	<CR>'S'	

3.0 CONSOLE FUNCTIONS

3.2 ***** START *****

165256	001002			BNE	2\$	
165260	000005			RESET		
165262	000115			JMP	(R5)	
165264	012704	173000	2\$:	MOV	173000,R4	
165270	031427	000200	3\$:	BIT	(R4),#200	;NO ROM?
165274	001323			BNE	DSPLY	;YEA,GO BACK,ABORT SEARCH.
165276	022402			CMP	(R4)+,R2	;MATCH ON BOOT HEADER VERSES CMMD?
165300	001405			BEQ	4\$;YES!--GO AHEAD.
165302	061404			ADD	(R4),R4	;NO-ADD INDEX TO GET TO NEW BOOT HEADER.
165304	020427	174000		CMP	R4, 174000	;HAVE WE EXCEEDED ROM RANGE?
165310	001731			BEQ	CONSEM	
165312	000766			BR	3\$;LOOP UNTILL MATCH OR TRAPS OUT.
165314	010701		4\$:	MOV	PC,R1	
165316	000423			BR	GETNUM	
165320	000005			RESET		;INIT SYSTEM
165322	113705	173024		MOVB	@#INITSW,R5	;GET MICRO SWITCHES.
165326	106105			ROLB	R5	;ASSUMES HERE THAT THAE STARTING
165330	106105			ROLB	R5	;ADDR. OF DISPLY IS 165144
						;SO C BIT GETS SET.
165332	000164	000010	5\$:	JMP	10(R4)	;GO DO BOOT.

3.3 ***** DEPOSIT *****

165336	010701		DE:	MOV	PC,R1	
165340	000412			BR	GETNUM	;GET INPUT DATA.
165342	010015			MOV	R0,(R5)	;PUT INPUT DATA IN MEMORY.
165344	000713			BR	CONSEM	;RETURN FOR NEXT COMMAND.

3.4 ***** LOAD ADDRESS *****

165346	010701		LA:	MOV	PC,R1	
165350	000406			BR	GETNUM	;GET INPUT DATA.
165352	010005			MOV	R0,R5	;LEAVE IT AS THE CURRENT ADDRESS
						;POINTER IN R5.
165354	005004		KBDCLR:	CLR	R4	;CLEAR THE PREVIOUS COMMAND FLAG.
165356	000706			BR	CONSEM	;RETURN FOR NEXT COMMAND.

3.5 ***** EXAMINE *****

165360	010506		EX:	MOV	R5,SP	;USE THE DISPLAY ROUTINE TO PRINT
165362	011505			MOV	(R5),R5	;OUT THE ADDRESS, R5, AND THE DATA IN THAT
165364	000675			BR	OUT	;ADDRESS, (R5).

4.0 TTY HANDLERS

4.1 OCTAL NUMBER INPUT ROUTINE

4.2 OCTAL NUMBER OUTPUT ROUTINE

4.3 CR,LF, AND FILLER CHARACTER OUTPUT ROUTINE

4.4 CHARACTER INPUT ROUTINE

4.5 CHARACTER OUTPUT ROUTINE

4.6 REGISTER DISPLAY ROUTINE

4.0 TTY HANDLERS

4.1 ***** OCTAL NUMBER INPUT ROUTINE *****

;THIS ROUTINE IS CALLED BY PLACING THE RETURN ADDRESS MINUS TWO
 ;IN R1 AND THEN BRANCHING TO GETNUM. THE ROUTINE WILL ATTEMPT TO
 ;INPUT A STRING OF CHARACTERS FROM THE TELETYPE, TERMINATED BY CR,
 ;AND ASSEMBLE THEM AS A 16 BIT OCTAL NUMBER IN R0. IF AN ILLEGAL
 ;CHARACTER IS TYPED IN THE STRING, NOT AN
 ;OCTAL DIGIT, THE CONSOLE EMULATOR WILL BE RESTARTED. THE PREVIOUS
 ;CONTENTS OF R2 AND R3 ARE LOST. THE ROUTINE WILL RETURN WITH THE
 ;OCTAL NUMBER IN R0, TO THE ADDRESS SPECIFIED IN R1 PLUS TWO.
 ;BUT NOTE THAT R1 WILL HAVE BEEN INCREMENTED BY FOUR UPON RETURN.

165366	005000	GETNUM: CLR	R0	;INITIALIZE R0.
165370	005002	2\$: CLR	R2	;INITIALIZE R2.
165372	010703		MOV PC,R3	;GO GET A CHARACTER.
165374	000453		BR GETCHR	
165376	120227	000015	CMPB R2,#CR	;IS IT CR?
165402	001433		BEQ X1RTN	;IF YES RETURN WITH THE NUMBER IN R0.
165404	162702	000070	SUB - '8,R2	;IS THE CHARACTER A LEGAL OCTAL DIGIT?
165410	062702	000010	ADD #'8-'0,R2	
165414	103357		BCC KBDCLR	;IF NOT GO RESTART THE CONSOLE EMULATOR.
165416	006300		ASL R0	;OTHERWISE ASSEMBLE THE NUMBER.
165420	006300		ASL R0	
165422	006300		ASL R0	
165424	050200		RIS R2,R0	
165426	000760		BR 2\$;LOOP BACK FOR NEXT CHARACTER.

4.0 TTY HANDLERS

4.2 ***** OCTAL NUMBER OUTPUT ROUTINE *****

;THIS ROUTINE, PUTNUM, IS CALLED BY PLACING THE RETURN ADDRESS
 ;MINUS TWO IN R1 AND THE 16 BIT OCTAL NUMBER TO BE TYPED
 ;IN R0. PUTNUM WILL TYPE 6 CHARCTERS COMPRISING THE OCTAL DIGITS
 ;OF THE NUMBER IN R0 FOLLOWED BY ONE SPACE CHARCTER. THE PREVIOUS
 ;CONTENTS OF R2 AND R3 ARE LOST. RETURN IS MADE TO THE ADDRESS
 ;IN R1 PLUS TWO, BUT R1 IS INCREMENTED BY FOUR.

165430	012702	PUTNUM: MOV	(PC)+,R2	;COMPUTE FIRST DIGIT.
165432	000030		.WORD	<'0>/2
165434	000261		SEC	
165436	006100	2\$:	ROL	R0 ;SHIFT NUMBER INTO R2 TO COMPUTE NEXT CHARACTER.
165440	106102		ROLB	R2
165442	010703		MOV	PC,R3 ;PRINT CHARACTER.
165444	000435		BR	PUTCHR
165446	012702		MOV	(PC)+,R2 ;GET READY TO COMPUTE NEXT CHARACTER.
165450	206		.BYTE	200!<'0/10>
165451	040		.BYTE	<' >
165452	006300	4\$:	ASL	R0 ;SHIFT NUMBER AND SEE IF DONE.
165454	001403		BEQ	6\$;BRANCH IF DONE.
165456	106102		ROLB	R2
165460	103774		RCS	4\$
165462	000765		BR	2\$
165464	000302	6\$:	SWAB	R2 ;WHEN DONE COME HERE TO PRINT SPACE.
165466	010703		MOV	PC,R3
165470	000423		BR	PUTCHR
165472	022121	X1RTN:	CMP	(R1)+,(R1)+ ;AND RETURN.
165474	000161		JMP	-2(R1)

4.3 ***** CR, LF AND FILLER CHARACTER OUTPUT ROUTINE *****

;THIS ROUTINE IS CALLED TO TYPE A CARRIAGE RETURN, LINE FEED FOLLOWED
 ;BY 12 FILLER CHARACTERS. THE CALL IS MADE BY FIRST PLACING THE RETURN
 ;ADDRESS MINUS TWO IN R1 AND EXECUTING BR PUTCR.
 ;THE PREVIOUS CONTENTS OF BOTH REGISTERS R2 AND R3 ARE LOST.
 ;WHEN FINISHED THIS SUBROUTINE WILL RETURN TO THE ADDRESS SPECIFIED
 ;IN R1 PLUS TWO, BUT R1 WILL BE INCREMENTED BY FOUR.

165500	012702	PUTCR: MOV	(PC)+,R2
165502	014012		.WORD
165504	010703	1\$:	MOV
165506	000414		PC,R3
165510	061702		BR
165512	003767		PUTCHR
165514	105002		ADD
165516	152702		(PC),R2
165522	000770		BLF
			X1RTN
			CLRB
			R2
			RISR
			- CR,R2
			BR
			1\$

4.0 TTY HANDLERS

4.4 ***** CHARACTER INPUT ROUTINE *****

;THIS ROUTINE IS CALLED TO BOTH INPUT AND ECHO A CHARACTER FROM
 ;THE TTY. THE CHARACTER IS SAVED IN THE LOW BYTE OF R2. THE
 ;HIGH BYTE OF R2 IS NOT MODIFIED. A CALL TO THIS
 ;SUBROUTINE IS MADE BY FIRST PLACING THE RETURN ADDRESS MINUS 2 IN R3
 ;AND THEN EXECUTING A BRANCH TO GETCHR. WHEN FINISHED
 ;A RETURN WILL BE MADE TO THE ADDRESS SPECIFIED IN R3 PLUS TWO, BUT
 ;R3 WILL HAVE BEEN INCREMENTED BY FOUR.

165524	105737	177560	GETCHR: TSTB	@#TKS	;WAIT FOR KEYBOARD INPUT, READY.
165530	100375		BPL	GETCHR	
165532	105002		CLRB	R2	;CLEAR THE LOW BYTE OF R2.
165534	153702	177562	BISB	@_TKB,R2	;PLACE THE CHARACTER IN THE LOW BYTE OF R2.
					;PROCEED ON TO PUTCHR IN ORDER TO
					;ECHO THE CHARACTER IN THE LOW BYTE
					;OF R2.

4.5 ***** CHARACTER OUTPUT ROUTINE *****

;THIS SUBROUTINE IS CALLED TO PRINT A CHARACTER. THE CHARACTER
 ;MUST BE PLACED IN THE LOW ORDER BYTE OF R2. TO CALL THIS ROUTINE
 ;PLACE THE RETURN ADDRESS MINUS TWO IN R3 AND BRANCH TO
 ;PUTCHR. THE CONTENTS OF R2 ARE NOT MODIFIED. RETURN IS MADE
 ;TO THE ADDRESS SPECIFIED IN R3 PLUS TWO, BUT R3 IS LEFT INCREMENTED
 ;BY FOUR.

165540	105737	177564	PUTCHR: TSTB	@#TPS	;WAIT FOR PRINTER READY.
165544	100375		BpL	PUTCHR	
165546	110237	177566	MOVB	R2,@#TPB	;WHEN READY PRINT THE CHARACTER.
165552	142702	100200	BICB	#100200,R2	;CLEAR ANY PARITY BITS THAT MAY BE SET.
					;THIS ROUTINE IS USED TO MAKE RETURNS FROM SUBROUTINES WHICH USE
					;R3 AS AN ADDRESS LINK. THOSE SUBROUTINES ARE CALLED
					;BY PLACING THE RETURN ADDRESS MINUS 2 IN R3. WHEN THE SUBROUTINE
					;IS FINISHED PROCESSING IT WILL BRANCH TO X3RTN. X3RTN
					;WILL INCREMENT R3 BY FOUR BUT RETURN TO THE ADDRESS SPECIFIED IN R3
					;PLUS TWO.
165556	022323		X3RTN: CMP	(R3)+,(R3)+	;INCREMENT R3 BY 4.
165560	000163	177776	JMP	-2(R3)	;RETURN TO THE ADDRESS WHICH WAS
					;ORIGINALLY IN R3 PLUS TWO.

4.6 ***** REGISTER DISPLAY ROUTINE *****

;DSPLY IS THE FIRST PART OF THE CONSOLE EMULATOR THAT IS EXECUTED.
 ;IT WILL PRINT THE CONTENTS OF R0, R4, R6 AND R5 (IN THAT ORDER) AS
 ;FOUR SIXTEEN BIT OCTAL NUMBERS ON THE TTY. NOTE THAT ON SOME ELEVEN
 ;SYSTEMS (E.G. THE 11/04) WHEN THE BOOT SWITCH IS DEPRESSED AND
 ;THE PROCESS OF BOOTING INITIATED THE PC WILL BE PLACED INTO R5.

5.0 SECONDARY CPU DIAGNOSTICS

5.1 DOUBLE OPERAND, MODIFYING INSTRUCTIONS, BYTE REFERENCE TEST

5.2 JSR TEST WITH MODES 1 AND 6

5.0 SECONDARY CPU DIAGNOSTICS

;THESE ARE THE MEMORY MODIFYING TESTS. THEY ARE RUN AS SUBROUTINE
 ;WHICH IS CALLED BY PLACING THE RETURN ADDRESS IN THE CALLING
 ;ROUTINE MINUS TWO IN R1. THE PREVIOUS CONTENTS OF R2,
 ;R3, R5 AND R6 ARE LOST. IF ANY OF THESE TESTS DETECTS AN ERROR
 ;A HALT WILL BE EXECUTED. THE USER CAN THEN CONSULT THIS LISTING
 ;FOR FURTHER INFORMATION ABOUT THE FAULT. ISSUING A
 ;CONTINUE FUNCTION WILL NOT BE MEANINGFUL AFTER
 ;ANY OF THESE TESTS DETECTS AN ERROR AND HALTS. NOTE THAT
 ;WHEN THE MEMORY TEST DETECTS A FAILURE AND HALTS CERTAIN
 ;IMPORTANT PARAMETERS USED IN THAT TEST WILL BE SAVED IN THE
 ;REGISTERS. THESE REGISTERS ARE INCLUDED IN THOSE WHICH ARE
 ;DISPLAYED WHEN THE CONSOLE EMULATOR PORTION OF THIS ROM
 ;IS INITIATED. SO THAT IF A MEMORY ERROR IS DETECTED THE USER
 ;CAN START THE CONSOLE EMULATOR TO EASILY ACCESS THIS MEMORY
 ;ERROR DATA. CAUTION SHOULD BE OBSERVED WHEN SELECTING THESE
 ;TESTS TO BE RUN. THEY WILL DESTROY THE PREVIOUS CONTENTS
 ;OF ANY MAIN MEMORY AVAILABLE UP TO 28K WORDS.

5.1 ***** DOUBLE OPERAND, MODIFYING INSTRUCTIONS, BYTE REFERENCE TEST. *****

165564	012705	165006	TEST6:	MOV	#T6DATA,R5	;SET UP TEST DATA ADDRESS.
165570	012702	000500		MOV	#500,R2	;SET UP DEST ADDRESS.
165574	011503			MOV	(R5),R3	;SET UP CMP OPERAND FOR TEST.
165576	005012			CLR	(R2)	;CLR 500.
165600	112512			MOVB	(R5)+,(R2)	;500=000377.
165602	005202			INC	R2	;POINTER TO UPPER BYTE, 501.
165604	112512			MOVB	(R5)+,(R2)	;500=177777.
165606	005302			DEC	R2	;MOVE POINTER BACK TO LOW BYTE.
165610	023512			CMP	@(R5)+,(R2)	;CHECK FOR ALL ONES.
165612	001015			BNE	T6ERR	
165614	005202			INC	R2	;MOVE POINTER UP TO ODD BYTE.
165616	143522			BICB	@(R5)+,(R2)+	;CLEAR HIGH BYTE OF LOCATION 500.
165620	024542			CMP	-(R5),-(R2)	;MOVE POINTERS BACK.
165622	143522			BICB	@(R5)+,(R2)+	;CLEAR LOW BYTE OF LOCATION 500.
165624	001010			BNE	T6ERR	;BRANCH IF NOT ZERO.
165626	010502			MOV	R5,R2	;GET DEFERRED ADDRESS OF 500 INTO R2.
165630	016505	177772		MOV	-6(R5),R5	;GET TEST DATA.
165634	110532			MOVB	R5,@(R2)+	;500 SHOULD BE 000377.
165636	150572	000000		BISB	R5,@(R2)	;SET UPPER BITS.
165642	020352			CMP	R3,@-(R2)	;CHECK FOR ALL ONES, 177777.
165644	001407			BEQ	TEST7	;IF NO ERROR GO TO NEXT TEST.
165646	000000		T6ERR:	HALT		

5.0 SECONDARY CPU DIAGNOSTICS

5.2 ***** JSR TEST WITH MODES 1 AND 6. *****

165650	005723		TSTJSR: TST	(R3)+	;R3 SHOULD POINT TO ZERO WORD AT T7ERR.
165652	001011			BNE T7ERR	;IF NOT THEN HALT ON ERROR.
165654	021605			CMP (SP),R5	;SP SHOULD POINT TO 177777.
165656	001007			BNE T7ERR	;IF NOT THEN HALT ON ERROR.
165660	000203			RTS R3	
165662	000000			HALT	
165664	011206		TEST7:	MOV (R2),SP	;SET UP STACK TO START AT 502.
165666	012702	165650		MOV #TSTJSR,R2	;SET UP ADDRESS FOR JSR.
165672	005726			TST (SP)+	;MOVE SP UP ONE WORD.
165674	004312			JSR R3,(R2)	;EXECUTE JSR TO TSTJSR.
165676	000000		T7ERR:	HALT	
165700	004362	000004		JSR R3,4(R2)	;EXECUTE JSR TO TSTJSR+4.

6.0 MEMORY DIAGNOSTIC AND SIZE ROUTINES

6.0 MEMORY DIAGNOSTIC AND SIZE ROUTINES

```

;THIS ROUTINE PERFORMS BOTH A DUAL ADDRESSING TEST AND A RUDIMENTARY
;DATA INTEGRITY TEST OF ANY MEMORY AVAILABLE UP TO 28K WORDS.
;FIRST EVERY LOCATION IS WRITTEN WITH ITS OWN ADDRESS, STARTING
;FROM LOCATION 0 AND WORKING UP. THEN AFTER EVERY LOCATION HAS
;BEEN WRITTEN WITH ITS OWN ADDRESS, THE ROUTINE RETURNS TO LOCATION
;0 AND NEGATES ITS CONTENTS. THEN THE
;ADDRESS OF THE LOCATION WHICH WAS JUST NEGATED IS ADDED TO
;THAT LOCATION. THE RESULT SHOULD BE ZERO. THE PROCESS IS CONTINUED
;FROM 0 TO THE TOP OF MEMORY. IF NO ERRORS ARE DETECTED MEMORY
;WILL BE LEFT FILLED WITH ZEROES. IF AN ERROR IS DETECTED THEN;
;      1      THE ADDRESS BEING TESTED IS LEFT IN R4
;      2      THE EXPECTED DATA FROM THAT LOCATION IS IN R6
;      3      THE FAILING DATA IS IN R0
;      4      FINALLY THE HALT AT LOCATION 165776 IN THIS
;              ROM IS EXECUTED.

```

```

165704      MEMTST:
165704 012705 160000      SIZE:  MOV    #160000,R5      ;SET UP R5.
165710 005037 000006      CLR     @#6              ;SET UP TRAP VECTOR 4.
165714 012737 165722 000004      MOV    #1$,@#4
165722 012706 000502      1$:    MOV    #502,SP      ;SET UP THE STACK POINTER.
165726 005745      TST     -(R5)          ;MAKE THE REFERENCE AND DECREMENT R5.
165730 005003      CLR     R3              ;R3 IS A POINTER USED TO READ AND WRITE MEMORY.
165732 010313      2$:    MOV    R3,(R3)        ;WRITE THE CONTENTS OF R3 INTO THE LOCATION
                                           ;ADDRESSED BY R3.
165734 005723      TST     (R3)+          ;INCREMENT R3 BY 2.
165736 020305      CMP     R3,R5          ;R5 CONTAINS THE LAST AVAILABLE MEMORY
                                           ;ADDRESS UNDER 28K WORDS. SEE IF
                                           ;THE END OF MEMORY HAS BEEN REACHED.
165740 101774      BLOS    2$              ;LOOP UNTIL DONE.
165742 005003      CLR     R3              ;RETURN R3 TO LOCATION 0.
165744 005413      4$:    NEG     (R3)        ;NEGATE THE LOCATION REFERENCED BY R3.
165746 060313      ADD     R3,(R3)        ;ADD THE CONTENTS OF R3.
165750 005723      TST     (R3)+          ;INCRMENT THE POINTER, R3, BY 2; AND SEE IF THE
                                           ;RESULT OF THE ADDITION WAS 0.
165752 001004      BNE     MEMERR          ;IF NOT 0, THEN AN ERROR HAS OCCURRED,
165754 020305      CMP     R3,R5          ;OTHERWISE CONTINUE UP UNTIL THE TOP
                                           ;OF MEMORY IS REACHED.
165756 101772      BLOS    4$
165760 000164 000002      ENDTST: JMP    2(R4)
                                           ;RESULT IN A TRAP THEN RETURN
                                           ;WITH THE HIGHEST MEMORY ADDRESS
                                           ;AVAILABLE IN R5.
                                           ;IF A MEMORY ERROR IS DETECTED COME HERE TO SAVE IMPORTANT
                                           ;PARAMETERS IN THE REGISTERS AND HALT.

165764 014304      MEMERR: MOV    -(R3),R4
165766 010300      MOV     R3,R0
165770 005006      CLR     SP
165772 000000      HALT
165774 040460      .ASCII  "0A"          ;IDENTIFIES ROM AS "A0" OR A VERSION 0 ECB 12-12-77
1012 165776 123162      .WORD    123162      ;CRC WORD FOR LAST 255. WORDS.
1013      000001      .END

```

248F1.P11 SYMBOL TABLE

BIT8 = 000400	BIT9 = 001000	CONSEM 165174	CR = 000015
CRCWD = 000000	DE 165336	DIAG = 165564	DL11CR= 177560
DSPLY 165144	ENDTST 165760	EX 165360	GETCHR 165524
GETNUM 165366	HBOOT 165000	HSRCR = 177550	INITSW= 173024
JMP1 165110	JMP2 165120	JMP2A 165122	KBDCLR 165354
LA 165346	LF = 000012	MEMERR 165764	MEMTST 165704
MRESER= 173000	OUT 165160	PC =%000007	PC11CR= 177550
PDIAG 165564	POOL 165000	PSW = 177776	PUTCHR 165540
PUTCR 165500	PUTNUM 165430	READ 165210	RESERV= 000340
RK05CR= 177404	RK06CR= 177440	RL01CR= 174400	RP03CR= 176714
RP04CR= 176700	RS03CR= 172040	RS04CR= 172040	RX01CR= 177170
RX02CR= 177170	R0 =%000000	R1 =%000001	R2 =%000002
R3 =%000003	R4 =%000004	R5 =%000005	R6 =%000006
R7 =%000007	SIZE 165704	SP =%000006	SWR = 177570
TEST1 165020	TEST2 165054	TEST3 165106	TEST4 165124
TEST6 165564	TEST7 165664	TKB = 177562	TKS = 177560
TPB = 177566	TPS = 177564	TSTJSR 165650	TTCR = 177560
TU10CR= 172522	TU16CR= 172440	TU56CR= 177342	T4DATA 165004
T6DATA 165006	T6DAT1 165014	T6ERR 165646	T7ERR 165676
X1RTN 165472	X3RTN 165556	. = 166000	

SECTION 2

ROM 23-616F1

TABLE OF CONTENTS

OPERATIONAL NOTES

TEST1 THIS TEST VERIFIES THE UNCONDITIONAL BRANCH
TEST2 TEST "CLR", MODE "0", AND "BMI","BVS","BHI","BLT","BLOS"
TEST3 TEST "DEC", MODE "0", AND "BPL","REQ","BGE","BLE"
TEST4 TEST "ROR, MODE "0", AND "BVC","BHS","BNE"
TEST5 TEST REGISTER DATA PATH
TEST6 TEST "ROL", "BCC", "BLT"
TEST7 TEST "ADD", "INC", "COM", AND "BCS", "BLE"
TEST10 TEST "ROR", "DEC", "BIS", "ADD", AND "BLO"
TEST11 TEST "COM", "BIC", AND "BGT", "BLE"
TEST12 TEST "SWAB", "CMP", "BIT", AND "BNE", "BGT"
TEST13 TEST "MOVB", "SOB", "CLR", "TST" AND "BPL", "BNE"
TEST14 TEST "JSR", "RTS", "RTI", "_JMP"
TEST15 TEST MAIN MEMORY FROM VIRTUAL 001000 TO LAST ADDR.
CACHE MEMORY DIAGNOSTIC TESTS
TEST16 TEST CACHE DATA MEMORY

OPERATIONAL NOTES

1. OVERVIEW
2. INTERNAL SWITCH SETTING
 - A. POWER UP AND CONSOLE BOOT SWITCHES
 - B. OPTIONS AND THE MICRO SWITCH SETTINGS
3. BOOTSTRAPPING
4. DIAGNOSTIC TESTS
5. RESTARTING AT THE USER POWER FAIL ROUTINE
6. LOAD ADDRESS AND START PROCEDURE

OPERATIONAL NOTES

1. OVERVIEW

THE M9312 IS DESIGNED TO PROVIDE BOOTSTRAPPING CAPABILITIES FOR ALL PDP-11 SYSTEMS WITH OR WITHOUT THE CONSOLE SWITCH REGISTER. IN ADDITION TO PROVIDING BOOTSTRAPPING FUNCTIONS FOR ALL MAJOR PDP-11 DEVICES, THE M9312 INCLUDES ROUTINES FOR SOME BASIC CPU AND MEMORY GO-NOGO DIAGNOSTIC TESTS.

THIS BOOTSTRAP HAS BEEN DESIGNED FOR MAXIMUM FLEXIBILITY OF OPERATION. ITS FUNCTIONS MAY BE INITIATED AUTOMATICALLY AT A POWER UP, OR BY DEPRESSING THE CONSOLE BOOT SWITCH, OR BY A LOAD ADDRESS AND START SEQUENCE.

2. INTERNAL SWITCH SETTING

A SET OF EIGHT MICRO SWITCHES ARE LOCATED ON THE M9312 MODULE. THESE ARE USED BY THE ROUTINES TO DETERMINE WHAT ACTION IS TO BE TAKEN. THEY GIVE THE USER AUTOMATIC ACCESS TO ANY FUNCTION.

A. POWER UP AND CONSOLE BOOT SWITCHES

THE PRIMARY ACTIVATING PROCESSES FOR THE M9312 PROGRAMS ARE EITHER A POWER UP SEQUENCE OR THE ENABLING OF THE CONSOLE BOOT SWITCH.

TO ACTIVATE THE M9312 ON A POWER UP, SWITCH 2 IN THE M9312 MICRO SWITCH REGISTER MUST BE IN THE ON POSITION. IF THIS SWITCH IS OFF THEN A NORMAL TRAP TO LOCATION 24 TO EXECUTE THE USER POWER UP ROUTINE WILL OCCUR. WHEN THIS SWITCH IS ON THE OTHER SWITCHES, 3 THROUGH 10, WILL DETERMINE WHAT ACTION THE M9312 WILL TAKE WHEN THE POWER UP OCCURS (SEE MICRO SWITCH SETTING BELOW).

IF THE SYSTEM INCLUDES A CONSOLE BOOT SWITCH THEN ANY TIME THAT SWITCH IS PRESSED THE M9312 WILL BE ACTIVATED (SOME PROCESSORS MAY HAVE TO BE HALTED FOR THIS SWITCH TO HAVE ANY EFFECT). THE PROCESS USED TO ENTER THE ROM IS A "FAKE" POWER DOWN FOLLOWED BY A POWER UP CAUSED BY PRESSING THE BOOT SWITCH (NOTE THAT THE POSITION OF MICRO SWITCH 2 DESCRIBED ABOVE IS IRRELEVANT TO THE OPERATION OF THIS BOOT SWITCH). THIS RESULTS IN A NORMAL POWER UP SEQUENCE IN THE CPU. PRIOR TO THE POWER UP SEQUENCE, THE M9312 ASSERTS 773000 ON THE UNIBUS ADDRESS LINES. IN THE CASE OF THE 11/60, THE PROCESSOR ASSERTS 000224 ON THE BUS, WHICH IS ORED WITH THE 773000 ASSERTED BY THE M9312. THE 11/70 ASSERTS THE ENTIRE ADDRESS ON THE UNIBUS AS A FUNCTION OF JUMPER SETTINGS (SEE OR M9312 USER MANUAL.) THE NEW PC IS DETERMINED BY ROM LOCATION 773024 OR 773224 (WITH THE 11/60) INSTEAD OF FROM LOCATION 000024. THE NEW PC WILL BE THE LOGICAL 'OR' OF THE CONTENTS OF ROM LOCATION 773024 AND THE EIGHT MICRO SWITCHES ON THE M9312 MODULE (A SWITCH IN THE ON POSITION IS SEEN AS A ONE; LIKEWISE A SWITCH IN THE OFF POSITION IS A ZERO).

IN THIS WAY ALL THE M9312 OPTIONS ARE ACCESSABLE BY MERELY GIVING EACH OPTION A DIFFERENT STARTING ADDRESS. NOTE HERE THAT MICRO SWITCH NUMBER 10 IS OR'ED WITH BIT 1 OF THE DATA IN ROM LOCATION 773024, MICRO SWITCH NUMBER NINE IS OR'ED WITH BIT 2 ETC., AND THAT IT IS UNNECESSARY TO PROVIDE A SWITCH WHICH IS OR'ED WITH DATA BIT 0 AS THIS COULD RESULT IN AN ODD ADDRESS WHEN GOING THROUGH THE TRAP TO LOCATION 773024 SEQUENCE.

B.OPTIONS AND THE MICRO SWITCH SETTINGS.

THE SETTING OF THE MICRO SWITCHS DEPENDS ON THE VARIOUS ROMS ON THE M9312 AND THE DEVICE BOOTS POSTION ON THE M9312.

3. BOOTSTRAPPING

THESE ROUTINES TO BOOTSTRAP A DEVICE TYPICALLY READ IN THE FIRST SECTOR, BLOCK OR 512 (DEC) WORDS, OFF THE DEVICE INTO LOCATION 0 THROUGH 512 (DEC) OF MEMORY. THE EXCEPTIONS TO THIS RULE ARE THE PAPER TAPE BOOT, THE FLEXIBLE DISK BOOT AND THE MAGNETIC TAPE BOOTS. THE PAPER TAPE BOOT IS UNIQUE IN THAT IT CAN DO NO ERROR CHECKING AND THAT THE SECONDARY BOOTSTRAP (THE ABSOLUTE LOADER, FOR EXAMPLE) IS READ INTO THE UPPER PART OF MEMORY. THE ACTUAL LOCATIONS LOADED BY THE PAPER TAPE BOOT ARE PARTIALLY DETERMINED BY THE SECONDARY BOOTSTRAP ITSELF AND BY THE 'SIZE' ROUTINE WHICH DETERMINES THE HIGHEST AVAILABLE MEMORY ADDRESS WITHIN THE FIRST 28K. THE FLEXIBLE DISK (OR FLOPPY) READS SECTOR 1 ON TRACK 1 INTO LOCATIONS STARTING AT ZERO. THE MAGNETIC TAPE BOOTS READ THE SECOND BLOCK INTO LOCATIONS STARTING AT 0. IF NO ERRORS ARE DETECTED IN THE DEVICE, THE BOOTSTRAPS NORMALLY TRANSFER CONTROL TO LOCATION 0 IN ORDER TO EXECUTE THE SECONDARY BOOTSTRAP JUST LOADED. THE ONLY EXCEPTION TO THIS STARTING ADDRESS IS WITH THE PAPER TAPE BOOTS. THEY TRANSFER CONTROL TO LOCATION XXX374, WHERE XXX WAS DETERMINED INITIALLY BY THE SIZE ROUTINE TO BE AT THE TOP OF MEMORY; THIS IS WHERE THE ABSOLUTE LOADER WAS JUST LOADED.

IF A DEVICE ERROR IS DETECTED A RESET WILL BE EXECUTED AND THE BOOTSTRAP WILL TRY AGAIN. THE BOOTSTRAP WILL BE RETRIED INDEFINITELY UNTIL IT SUCCEEDS WITHOUT ERROR UNLESS THE USER (OPERATOR) INTERVENES. THE ADVANTAGE OF RETRYING THE BOOT IS THAT IF A PARTICULAR DEVICE BEING BOOTED IS NOT ONLINE OR LOADED, SAY BECAUSE OF A POWER FAILURE RESTART, THE BOOT WILL GIVE THE DEVICE A CHANCE TO POWER UP (FOR DISKS THIS IS ESSENTIAL). A MAGNETIC TAPE TRANSPORT WILL NOT AUTOMATICALLY RELOAD ITSELF AFTER A POWER FAILURE AND RESTART. THIS SITUATION REQUIRES USER INTERVENTION. THE USER MUST RELOAD THE MAGTAPE AND BRING IT BACK ONLINE AT WHICH TIME THE MAGTAPE BOOTSTRAP, WHICH WAS CONTINUALLY ATTEMPTING TO BOOT THE TAPE, WILL SUCCEED.

NOTE:: AN EXCEPTION TO THIS RULE ARE DEVICE BOOTS FOR THE
RK06/RK07 AND RX02.
IN THE CASE OF THE RK06, IF A DRIVE TYPE ERROR IS
ENCOUNTERED, THE DRIVE IS SET TO AN RK07.
IN THE CASE OF AN RX02, FIRST DOUBLE DENSITY IS TRYED,
SOULD WE GET A DENSITY ERROR ON READ TRY, WE CHANGE
THE DENSITY TO SINGLE DENSITY. IN EITHER CASE, WE
READ TWO (2) SECTORS OF DATA.

SOME BOOTS ALLOW POWER-UP OR BOOT SWITCH BOOTING FOR
DRIVES OTHER THAN DRIVE 0. REFER TO INDIVIDUAL BOOTS FOR THIS
INFORMATION.

4. DIAGNOSTIC TESTS

THERE ARE THREE DIFFERENT TYPES OF TESTS INCLUDED IN
THE M9312 :

- 1 PRIMARY CPU TESTS
- 2 SECONDARY CPU TESTS
- 3 MEMORY TEST
- 4 CACHE TESTS

THE PRIMARY CPU TESTS ARE TESTS OF MOST UNARY AND
DOUBLE OPERAND INSTRUCTIONS WITH MOST SOURCE MODES. THESE
TESTS DO NOT MODIFY MEMORY. IF A FAILURE IS DETECTED A HALT
WILL OCCUR.

THE SECONDARY CPU TESTS MODIFY MEMORY AND INVOLVE
THE USE OF THE STACK POINTER. THESE TESTS INCLUDE TESTING
OF THE JMP AND JSR INSTRUCTIONS AS WELL AS TESTS OF ALL
DESTINATION MODES. IF A FAILURE IS DETECTED THESE TESTS
WILL ALSO EXECUTE A HALT. THE USER MAY THEN CONSULT THIS
LISTING TO DETERMINE THE FAULT CLASS FOR THE PARTICULAR LOCATION
THE TEST HALTED.

THE MEMORY TEST PERFORMS BOTH A DUAL
ADDRESSING AND DATA CHECK OF ALL THE AVAILABLE MEMORY ON THE
SYSTEM LESS THAN 28K. THIS TEST WILL CHANGE ALL OF MEMORY
TESTED. LIKE THE SECONDARY TESTS THE MEMORY TEST WILL HALT
WHEN AN ERROR IS DETECTED. AT THE TIME THE MEMORY ERROR
HALT IS EXECUTED R0 WILL CONTAIN THE ADDRESS AT WHICH THE
FAILURE WAS DETECTED. R1 WILL CONTAIN THE FAILING DATA
PATTERN AND R0 WILL CONTAIN THE EXPECTED DATA PATTERN.

FINALLY THERE ARE TWO CACHE TESTS WHICH DETERMINE
CPU TYPE (11/60 OR 11/70) AND TEST CACHE CONTROLS, DATA
INTEGRITY AND MEMORY VIA CACHE. FOR DETAILS, SEE TESTS
16 AND 17 OF THE PROGRAM LISTING.

NOTE: HERE THAT DIAGNOSTICS ARE RUN OR NOT RUN (OPTIONALLY) DEPENDING ON WHETHER BIT 1 IS CLEAR OR SET (RESPECTIVELY) IN EITHER:

- 1 THE INTERNAL MICRO SWITCHES DESCRIBED ABOVE (IF THE POWER UP OR CONSOLE BOOT SWITCH METHOD IS USED); OR
- 2 THE CONSOLE SWITCH REGISTER (IF THE LOAD ADDRESS AND START WITH OPTION CODE IN SWITCHES METHOD DESCRIBED BELOW IS USED).

5. RESTARTING AT THE USER POWER FAIL ROUTINE

IF THE USER WISHES TO RESTART HIS OWN SOFTWARE ON A POWER UP HE MAY DO SO BY MERELY DISABLING THE POWER FAIL RESTART SWITCH IN THE MICRO SWITCHES (TURN SWITCH 2 OFF).

6. LOAD AND START PROCEDURE

11/60/70 DIAGNOSTIC ROM

THERE ARE NO SPECIAL M9312 SWITCH SETTINGS THAT PERTAIN TO THIS ROM. THE ONLY WAY THESE DIAGNOSTICS CAN BE EXECUTED IS BY ENTERING A BOOTSTRAP AT AN ENTRY POINT THAT CALLS FOR DIAGNOSTICS TO BE RUN.

THIS ROM ALLOWS BOOTING VIA CONSOLE SWITCH REGISTER. THIS CAN BE DONE AS FOLLOWS:

- 1.LOAD ADDRESS 765744
- 2.SET SWITCH REGISTER AS SHOWN BELOW

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
NA	NA	NA	NA												
OCTAL UNIT								SWR CODE FROM BOOT ROM TABLES							
NUMBER															

- 3. NOW START
- NOTE: THE SWR CODES ARE CONTAINED IN THE BOOT ROM TABLES OF K-SP-M9312-0-4 (SET-UP AND INSTALLATION PROCEDURE.

```

                                .ABS
                                MJS=14
                                GRP0=30
                                GRP1=44
                                .=165000
165000 010037 000700      START: MOV    R0,#700
165004 010137 000702      MOV    R1,#702
165010 010437 000704      MOV    R4,#704
165014 005037 000706      CLR     #706          ;SET FOR 11/70 IF ZERO.
165020 052737 100000 177776  BIS     #100000,#177776      ;SET BIT 15 IF 11/60,BIT 14 WILL SET
165026 032737 040000 177776  BIT     #40000,#177776      ;SEE IF 11/60
165034 001402              BEQ     1$              ;IF NOT SET,11/70
165036 005237 000706      INC     #706          ;SET ,WAS AN 11/60
165042 005037 177776      1$:   CLR     #177776      ;CLR PSW WORD.
                                ;*****
TEST1  THIS TEST VERIFIES THE UNCONDITIONAL BRANCH
                                ;*
                                ;*   THE REGISTERS AND CONDITION CODES ARE ALL UNDEFINED WHEN
                                ;*   THIS TEST IS ENTERED AND THEY SHOULD REMAIN THAT WAY UPON
                                ;*   THE COMPLETION OF THIS TEST.
                                ;*****
165046                                TST1:
165046 000401              BR      TST2              ; * BRANCH ALWAYS
165050 000000              HALT
                                ;*****
TEST2  TEST "CLR", MODE "0", AND "BMI","BVS","BHI","BLT","BLOS
                                ;*
                                ;*   THE REGISTERS AND CONDITION CODES ARE ALL UNDEFINED WHEN
                                ;*   THS TEST IS ENTERED. UPON COMPLETION OF THIS TEST THE "SP"
                                ;*   (R6) SHOULD BE ZERO AND ONLY THE "Z" FLIP-FLOP WILL BE SET.
                                ;*
                                ;*****
165052                                TST2:
165052 005006              CLR     SP              ;N=0,Z=1,V=0,C=0,SP=000000
165054 100404              BMI     1$              ; V BRANCH IF N=1
165056 102403              BVS     1$              ; V BRANCH IF V=1
165060 101002              BHI     1$              ; V BRANCH IF Z AND C ARE BOTH 0
165062 002401              BLT     1$              ; V BRANCH IF (N XOR V)=1
165064 101401              BLOS    TST3            ; * BRANCH IF (Z XOR C)=0
165066 000000      1$:   HALT
                                ;*****
TEST3  TEST "DEC", MODE "0", AND "BPL","BEQ","BGE","BLE"
                                ;*
                                ;*   UPON ENTERING THIS TEST THE CONDITION CODES ARE:
                                ;*   N = 0, Z = 1, V = 0, AND C = 0.
                                ;*   THE REGISTERS ARE: R0 = ?, R1 = ?, R2 = ?
                                ;*   R3 = ?, R4 = ?, R5 = ?, SP = 000000
                                ;*   UPON COMPLETION OF THIS TEST THE CONDITION CODES WILL BE:
                                ;*   N = 1, Z = 0, V = 0, AND C = 0
                                ;*   THE REGISTERS AFFECTED BY THE TEST ARE:
                                ;*   SP = 177777
                                ;*
                                ;*****

```

```

165070
165070 005306      TST3:      DEC      SP      ;N=1,Z=0,V=0,C=0,SP=177777
165072 100003      RPL      1$      ; V BRANCH IF N=0
165074 001402      BEQ      1$      ; V BRANCH IF Z=1
165076 002001      BGE      1$      ; V BRANCH IF (N XOR V)=0
165100 003401      BLE      TST4     ; * BRANCH IF (Z OR (N XOR V))=1
165102 000000      1$:      HALT
;*****
TEST4  TEST "ROR, MODE "0", AND "BVC","BHIS","BNE"
; *
; *      UPON ENTERING THIS TEST THE CONDITION CODES ARE:
; *      N = 1, Z = 0, V = 0, AND C = 0.
; *      THE REGISTERS ARE: R0=?, R1=?, R2 = ?
; *      R3 = ?, R4 = ?, R5 = ?, SP = 177777
; *      UPON COMPLETION OF THIS TEST THE CONDITION CODES WILL BE:
; *      N = 0, Z = 0, V = 1, AND C = 1
; *      THE REGISTERS AFFECTED BY THE TEST ARE:
; *      SP = 077777
; *
;*****
165104
165104 006006      TST4:      ROR      SP      ;N=0,Z=0,V=1,C=1,SP=077777
165106 102002      BVC      1$      ; V BRANCH IF V=0
165110 103001      BHIS     1$      ; V BRANCH IF C=0
165112 001001      BNE      TST5     ; * BRANCH IF Z=0
165114 000000      1$:      HALT
;*****
TEST5  TEST REGISTER DATA PATH
; *
; *      WHEN THIS TEST IS ENTERED THE CONDITION CODES ARE:
; *      N = 0, Z = 0, V = 1, AND C = 1.
; *      THE REGISTERS ARE: R0 = ?, R1 = ?, R2 = ?
; *      R3 = ?, R4 = ?, R5 = ?, SP = 077777.
; *      UPON COMPLETION OF THIS TEST THE CONDITION CODES ARE:
; *      N = 0, Z = 1, V = 0, AND C = 0.
; *      THE REGISTERS ARE LEFT AS FOLLOWS:
; *      R0 = 125252, R1 = 000000, R2 = 125252, R3 = 125252
; *      R4 = 125252, R5 = 125252, AND SP = 125252
; *
;*****
165116
165116 012706 125252 TST5:      MOV      #125252,SP  ;N=0,Z=0,V=0,C=1,SP=125252
165122 010600      MOV      SP,R0      ;N=0,Z=0,V=0,C=1,R0=125252
165124 010001      MOV      R0,R1      ;N=0,Z=0,V=0,C=1,R1=125252
165126 010102      MOV      R1,R2      ;N=0,Z=0,V=0,C=1,R2=125252
165130 010203      MOV      R2,R3      ;N=0,Z=0,V=0,C=1,R3=125252
165132 010304      MOV      R3,R4      ;N=0,Z=0,V=0,C=1,R4=125252
165134 010405      MOV      R4,R5      ;N=0,Z=0,V=0,C=1,R5=125252
165136 160501      SUB      R5,R1      ;N=0,Z=1,V=0,C=0, AND R1=000000
165140 002401      BLT      1$      ; V BRANCH IF (N XOR V)=1
165142 001401      BEQ      TST6     ; * BRANCH IF Z=1
165144 000000      1$:      HALT

```

```

TEST6  TEST "ROL", "BCC", "BLT"
;*****
;*
;*      WHEN THIS TEST IS ENTERED THE CONDITION CODES ARE:
;*      N = 0, Z = 1, V = 0, AND C = 0.
;*      THE REGISTERS ARE: R0 = 125252, R1 = 000000, R2 = 125252
;*      R3 = 125252, R4 = 125252, R45 = 125252, SP = 125252.
;*      UPON COMPLETION OF THIS TEST THE CONDITION CODES ARE:
;*      N = 0, Z = 0, V = 1, AND C = 1.
;*      THE REGISTERS ARE LEFT UNCHANGED EXCEPT FOR
;*      R2 WHICH SHOULD NOW EQUAL 052524.
;*
;*****
165146  TST6:
165146  006102      ROL      R2          ;N=0,Z=0,V=1,C=1, AND R2 = 052524
165150  103001      BCC      1$          ; V BRANCH IF C=0
165152  002401      BLT      TST7        ; * BRANCH IF (N XOR V)=1
165154  000000      1$:      HALT
;*****

TEST7  TEST "ADD", "INC", "COM", AND "BCS", "BLE"
;*
;*      WHEN THIS TEST IS ENTERED THE CONDITION CODES ARE:
;*      N = 0, Z = 0, V = 1, AND C = 1.
;*      THE REGISTERS ARE: R0 = 125252, R1 = 000000, R2 = 052524
;*      R3 = 125252, R4 = 125252, R5 = 125252, SP = 125252
;*      UPON COMPLETION OF THIS TEST THE CONDITION CODES ARE:
;*      N = 0, Z = 1, V = 0, AND C = 0.
;*      THE REGISTERS ARE LEFT UNCHANGED EXCEPT FOR
;*      R3 WHICH NOW EQUALS 000000, AND R1 WHICH IS ALSO 000000
;*
;*****
165156  TST7:
165156  060203      ADD      R2,R3        ;(R2 = 052524) + (R3 = 125252)
165160  005203      INC      R3          ;N=1,Z=0,V=0,C=0,AND R3=177776
165162  005103      COM      R3          ;N=1,Z=0,V=0,C=0, AND R3=177777
165164  060301      ADD      R3,R1        ;N=0,Z=1,V=0,C=1, AND R3=000000
165166  103401      BCS      1$          ;N=0,Z=1,V=0,C=0, AND R1 = 000000
165170  003401      BLE      TST10       ; V BRANCH IF C=1
165172  000000      1$:      HALT        ; * BRANCH IF (Z OR (N XOR V))=1
;*****

TEST10 TEST "ROR", "DEC", "BIS", "ADD", AND "BLO"
;*
;*      WHEN THIS TEST IS ENTERED THE CONDITION CODES ARE:
;*      N = 0, Z = 1, V = 0, AND C = 0.
;*      THE REGISTERS ARE: R0 = 125252, R1 = 000000, R2 = 052524
;*      R3 = 000000, R4 = 125252, R5 = 125252, SP = 125252.
;*      UPON COMPLETION OF THIS TEST THE CONDITION CODES ARE:
;*      N = 1, Z = 0, V = 0, AND C = 0.
;*      THE REGISTERS ARE LEFT UNCHANGED EXCEPT FOR
;*      R4 WHICH SHOULD NOW EQUAL 052525, AND
;*      R1 WHICH SHOULD NOW EQUAL 177777
;*
;*****

```

```

165174                                TST10:
165174 006004                        ROR      R4                ;N=0,Z=0,V=1,C=0, AND R4 = 052525
165176 050403                        BIS      R4,R3           ;N=0,Z=0,V=0,C=0, AND R3 = 052525
165200 060503                        ADD      R5,R3           ;N=1,Z=0,V=0,C=0, AND R3 = 177777
165202 005203                        INC      R3              ;N=0,Z=1,V=0,C=0, AND R3 = 000000
165204 103402                        BLO      1$              ; V BRANCH IF C=1
165206 005301                        DEC      R1              ;N=1,Z=0,V=0,C=0, AND R1 = 177777
165210 002401                        BLT      TST11           ; * BRANCH IF (N XOR V)=1
165212 000000                        1$:      HALT
; *
;*****
TEST11  TEST "COM", "BIC", AND "BGT", "BLE"
; *
; *      WHEN THIS TEST IS ENTERED THE CONDITION CODES ARE:
; *      N = 1, Z = 0, V = 0, AND C = 0.
; *      THE REGISTERS ARE: R0 = 125252, R1 = 177777, R2 = 052524
; *      R3 = 000000, R4 = 052525, R5 = 125252, SP = 125252.
; *      UPON COMPLETION OF THIS TEST THE CONDITION CODES ARE:
; *      N = 0, Z = 0, V = 1, AND C = 1.
; *      THE REGISTERS ARE LEFT UNCHANGED EXCEPT FOR
; *      R0 WHICH SHOULD NOW EQUAL 052525, AND
; *      R1 WHICH SHOULD NOW EQUAL 052524
; *
;*****
165214                                TST11:
165214 005100                        COM      R0                ;N=0,Z=0,V=0,C=1, AND R0 = 052525
165216 101401                        BLOS     2$              ; * BRANCH IF (Z OR C)=1
165220 000000                        HALT                      ;STOP HERE IF BRANCH FAILED
165222 040001                        2$:      BIC      R0,R1           ;N=1,Z=0,V=0,C=1, AND R1 = 125252
165224 060101                        ADD      R1,R1           ;N=0,Z=0,V=1,C=1, AND R1 = 052524
165226 003001                        BGT      1$              ; V BRANCH IF Z AND ( N XOR V) ARE BOTH 0
165230 003401                        BLE      TST12           ; * BRANCH IF (Z OR (N XOR V))=1
165232 000000                        1$:      HALT
; *
;*****
TEST12  TEST "SWAB", "CMP", "BIT", AND "BNE", "BGT"
; *
; *      WHEN THIS TEST IS ENTERED THE CONDITION CODES ARE:
; *      N = 0, Z = 0, V = 1, AND C = 1.
; *      THE REGISTERS ARE: R0 = 052525, R1 = 052524, R2 = 052524
; *      R3 = 000000, R4 = 052525, R5 = 125252, SP = 125252.
; *      UPON COMPLETION OF THIS TEST THE CONDITION CODES ARE:
; *      N = 0, Z = 0, V = 0, AND C = 1.
; *      THE REGISTERS ARE NOW:
; *      R0 = 052525, R1 = 052125, R2 = 052524, R3 = 000000
; *      R4 = 052525, R5 = 052525, SP = 125252.
; *
;*****
165234                                TST12:
165234 000301                        SWAB     R1                ;N=0,Z=0,V=0,C=0, AND R1 = 052125
165236 020127 052125                CMP      R1,#052125         ;N=0,Z=1,V=0,C=0
165242 001004                        BNE      1$              ; V BRANCH IF Z=0
;R4 = 052525 R5 = 125252
165244 030405                        BIT      R4,R5           ;N=0,Z=1,V=0,C=0
165246 003002                        BGT      1$              ; V BRANCH IF Z OR (N XOR V) ARE 0
165250 005105                        COM      R5                ;N=0,Z=0,V=0,C=1, AND R5 = 052525

```



```

165252 001001      BNE      TST13      ; * BRANCH IF Z=1
165254 000000      1$:      HALT
;*****
TEST13  TEST "MOVB", "SOB", "CLR", "TST" AND "BPL", "BNE"
; *
; *      WHEN THIS TEST IS ENTERED THE CONDITION CODES ARE:
; *      N = 0, Z = 0, V = 0, AND C = 1.
; *      THE REGISTERS ARE: R0 = 052525, R1 = 052125, R2 = 052524
; *      R3 = 000000, R4 = 052525, R5 = 052525, SP = 125252.
; *      UPON COMPLETION OF THIS TEST THE CONDITION CODES ARE:
; *      N = 0, Z = 1, V = 0, AND C = 0.
; *      R0 IS DECREMENTED BY A SOB INSTRUCTION TO 000000
; *      R1 IS CLEARED AND THEN INCREMENTED AROUND TO 000000
; *
;*****
165256      TST13:
165256 112700 177401      MOVB      #177401,R0      ;N=0,Z=0,V=0,C=1, AND R0 = 000001
165262 100001      BPL      2$      ; * BRANCH IF N=0
165264 000000      1$:      HALT      ;STOP IF "BPL" FAILED
165266 077002      2$:      SOB      R0,1$      ;DO NOT LOOP SINCE (R0 -1) = 0
165270 005001      CLR      R1      ;N=0, Z=1, V=0, C=0, AND R1 = 000000
165272 005201      3$:      INC      R1      ;INCREMENT 64K TIMES (2 ** 16)
165274 077002      SOB      R0,3$      ;LOOP BACK TO "INC" 64K TIMES
165276 005700      TST      R0      ;N=0,Z=1,V=0,C=0, AND R0 = 000000
165300 001002      BNE      4$      ; V BRANCH IF Z=0
165302 005701      TST      R1      ;N=0,Z=1,V=0,C=0, AND R1 = 000000
165304 001401      BEQ      TST14
165306 000000      4$:      HALT
;*****
TEST14  TEST "JSR", "RTS", "RTI", "JMP"
; *
; *      THIS TEST FIRST SETS THE STACK POINTER TO 776,
; *      AND THEN VERIFIES THAT "JSR", "RTS", "RTI", AND "JMP"
; *      ALL WORK PROPERLY.
; *
; *      ON ENTRY TO THIS TEST THE STACK POINTER "SP" IS INITIALIZED
; *      TO 00776 AND IS LEFT THAT WAY ON EXIT.
; *
;*****
165310      TST14:
165310 012706 000776      11$:     MOV      #776,SP      ;SET UP THE STACK POINTER
165314 004767 000002      JSR      PC,1$      ;TRY TO JSR TO 1$
165320 000000      10$:     HALT      ;THE "JSR" MUST HAVE FAILED
165322 022716 165320      1$:      CMP      #10$, (SP)      ;WAS THE CORRECT ADDRESS PUSHED?
165326 001401      BEQ      2$      ;BRANCH IF YES
165330 000000      HALT      ;WRONG THING PUSHED ON STACK
165332 012716 165342      2$:     MOV      #3$, (SP)      ;CHANGE THE ADDRESS ON THE STACK
165336 000207      RTS      PC      ;TRY TO RETURN TO 3$
165340 000000      HALT      ;DID NOT RETURN PROPERLY
165342 005046      3$:     CLR      -(SP)      ;PUSH A ZERO ON THE STACK
165344 012746 165354      MOV      #4$, -(SP)      ;PUSH THE RETURN ADDRESS ON STACK
165350 000002      RTI      ;SEE IF AN "RTI" WORKS
165352 000000      HALT      ;THE "RTI" FAILED
165354 000137 165362      4$:     JMP      @#5$      ;TRY TO "JMP"
165360 000000      HALT      ;THE "JMP" FAILED

```

```

165362          5s:          ;ADDRESS TO "JMP" TO
;*****
TEST15  TEST MAIN MEMORY FROM VIRTUAL 001000 TO LAST ADDR.
;*****
;*
;*      THIS TEST WILL TEST MAIN MEMORY WITH THE CACHE DISABLED, FROM
;*      VIRTUAL ADDRESS 001000 TO LAST ADDR. IF THE DATA DOES NOT COMPARE
;*      PROPERLY THE TEST WILL HALT AT EITHER 165516 OR 165536. IF A
;*      PARITY ERROR OCCURS THE TEST WILL HALT AT ADDRESS 165750, WITH
;*      THE PC + 2 ON THE STACK WHICH IS IN THE KERNEL D-SPACE.
;*
;*      IN THIS TEST THE REGISTERS ARE INITIALIZED AS FOLLOWS:
;*      R0 = 001000, R1 = DATA READ, R2 = 001000, R3 = 177746 (CACHE CONTROL REG.)
;*      R4 = COUNT VALUE, R5 = LAST MEMORY ADDRESS, SP = 000776
;*
;*****
165362          TST15:
165362  012705  160000          MOV      #160000,R5          ;FIRST GET SIZE OF MEMORY.
165366  005037  000006          CLR      @#6
165372  012737  165400  000004  MOV      #1s,@#4
165400  012706  000776          1s:  MOV      #776,SP
165404  005745          TST      -(R5)
;*****
;IN END,R5 CONTAINS LAST MEM ADDR.
165406          FIX:
;*****
165406  012737  165714  000114  10s:  MOV      #CONT,@#114          ;THE LAST MEMORY ADDRESS
165414  005037  000116          CLR      @#116          ;SET UP PARITY VECTOR
165420  012703  177746          MOV      #177746,R3          ;SET PROCESSOR STATUS WORD TO ZERO
165424  012713  000014          MOV      #MISS,(R3)          ;CACHE CONTROL REGISTER ADDRESS
165430  012702  001000          MOV      #1000,R2          ;FORCE MISS BOTH GROUPS
165434  010200          MOV      R2,R0          ;FIRST ADDRESS STORAGE
165436  010010          1s:  MOV      R0,R0          ;SETUP FORST ADDRESS
;LOAD EACH ADDRESS WITH ITS
;OWN ADDRESS
165440  005720          TST      (R0)+
165442  020005          CMP      R0,R5
165444  101774          BLOS      1s
165446  010200          MOV      R2,R0          ;SET STARTING ADDRESS IN R0
165450  011001          2s:  MOV      (R0),R1          ;GET THE DATA
165452  020001          CMP      R0,R1          ;IS IT CORRECT?
165454  001401          BEQ      3s          ;BRANCH IF YES
165456  000000          HALT          ;DATA ERROR ON READING MEMORY LOCATION
;R0 = ADDRESS, R1 = DATA RECEIVED, R0 = DATA EXPECTED
;COMPLEMENT DATA AND INCREMENT ADDRESS
165460  005120          3s:  COM      (R0)+
165462  020005          CMP      R0,R5
165464  101771          BLOS      2s
165466  014001          4s:  MOV      -(R0),R1          ;READ THE DATA (IT SHOULD NOW BE THE
;COMPLEMENT OF THE ADDRESS)
;COMPLEMENT BEFORE CHECKING
165470  005101          COM      R1          ;IS THE DATA CORRECT?
165472  020001          CMP      R0,R1          ;BRANCH IF YES
165474  001401          BEQ      5s          ;DATA ERROR ON READING MEMORY LOCATION
165476  000000          HALT          ;R0=ADDRESS, R1=DATA RECEIVED, R0=DATA EXPECTED
165500  020002          5s:  CMP      R0,R2
165502  001371          BNE      4s

```



```

165562 000402          BR      6$
165564 000167 177210    JMP      START          ;ENTRY POINT FROM ROM WITH DIAGNOSTIC SELECTED
165570 005720          6$:    TST      (R0)+        ;MOVE TO NEXT ADDRESS
165572 077223          SOB      R2,3$           ;BRANCH IF NOT DONE
165574 012713 000044    MOV      #GRP1,(R3)      ;FORCE MISS LOWER 1/2K OF CACHE ON 11/60
165600 012700 006000    MOV      #6000,R0
165604 105166 000001    COMB     1(SP)          ;COMPLEMENT THE CYCLE FLAG
165610 001344          BNE      1$             ;LOOP IF NOT DONE
;*****
TEST17  TEST MEMORY WITH THE DATA CACHE ON
;*
;*   THIS TEST CHECKS VIRTUAL MEMORY FROM 001000 THRU LAST ADDRESS
;*   TO INSURE THAT YOU CAN GET HITS ALL THE WAY UP THROUGH MAIN
;*   MEMORY. ON THE PDP11/70, IT STARTS WITH GROUP 1 ENABLED, THEN TESTS
;*   GROUP 0, AND FINALLY CHECKS MEMORY WITH BOTH GROUPS ENABLED.
;*   ON THE PDP11/60, THE TEST IS DONE WITH THE
;*   WHOLE CACHE ENABLED.
;*
;*   UPON ENTRY THE REGISTERS WILL BE SET UP AS FOLLOWS:
;*
;*   R0 = 001000 (ADDRESS), R1 = 3 (PASS COUNT), R2 = (FIRST ADDRESS),
;*   R3 = 177746 (CONTROL REG.),
;*   R5 = (LAST MEMORY ADDRESS, SP = 776
;*
;*   UPON COMPLETION OF THIS TEST MAIN MEMORY FROM VIRTUAL ADDRESS
;*   001000 THRU LAST ADDRESS WILL CONTAIN ITS OWN VIRTUAL ADDRESS.
;*****
165612 012702 001000    TST17:  MOV      #1000,R2          ;SETUP FIRST ADDRESS
165616 010200          MOV      R2,R0           ;FIRST ADDRESS IS 1000 OCTAL
165620 010010          1$:    MOV      R0,(R0)    ;FILL MEMORY WITH ADDRESSES
165622 005720          TST      (R0)+
165624 020005          CMP      R0,R5
165626 101774          BLOS     1$
165630 012701 000003    MOV      #3,R1          ;SET PASS COUNT TO THREE
165634 005016          CLR      (SP)
165636 005737 000706    TST      @#706         ;IF 11/60 THIS LOC=1,11/70=00
165642 001020          BNE      6$             ;IT IS PDP11/60
165644 012716 000030    MOV      #GRP0,(SP)     ;LOAD CODE TO FORCE GROUP 0 ONTO STACK
165650 010200          2$:    MOV      R2,R0           ;FIRST ADDRESS
165652 005110          3$:    COM      (R0)         ;DOUBLE COMPLEMENT DATA AND
165654 005110          COM      (R0)         ;MAKE SURE IT IS IN THE CACHE.
165656          51$:
165656 020010          CMP      R0,(R0)         ;COMPARE DATA, AND SET BIT 0 IN HIT/MISS REG.
;ALSO POINT TO NEXT ADDRESS
;BRANCH IF DATA MATCHES
;DATA DIDN'T MATCH R0 = ADDRESS + 2
165660 001401          BEQ      5$
165662 000000          HALT
165664 005720          5$:    TST      (R0)+
165666 006037 177752    ROR      @#177752      ;WAS THE LAST MEMORY REFERENCE A HIT?
165672 103402          BCS      4$             ;BRANCH IF YES
165674 000000          HALT                    ;HIT FAILED TO OCCUR R0 = ADDRESS + 2
165676 000410          BR      BOOTMISS        ;ABORT REST OF TEST IF "CONTINUE" PRESSED
165700 020005          4$:    CMP      R0,R5
165702 101763          BLOS     3$
165704 011613          6$:    MOV      (SP),(R3)    ;FORCE MISS GRP1 ON PASS 2, FULLY

```

165706	005016		CLR	(SP)	
165710	077121		SOB	R1,2\$	
165712	000404	JUMP0:	BR	JUMP	
165714	000000	CONT:	HALT		
;ENABLE CACHE ON PASS THREE. (11/70)					
;ON 11/60, RUN EACH PASS WITH THE SHOLE					
;CACHE ENABLED.					
;GET READY TO FULLY ENABLE CACHE ON PASS 3					
;RUN THREE PASSES THRU THIS TEST					
;GO TO BOOT STRAP CODE					
;STOP HERE IF THERE IS A CACHE PARITY ERROR					
;OR A MAIN MEMORY PARITY ERROR					
;CHECK CCR, MEMORY REGISTER AND CPU REGISTER					
;TO FIND WHICH ONE					
165716	000402		BR	JUMP	
165720		BOOTMISS:			
165720	012713	000014	MOV	#MISS,(R3)	
165724	013700	000700	JUMP:	MOV	#700,R0
165730	013701	000702		MOV	#702,R1
165734	013704	000704		MOV	#704,R4
165740	000164	000002		JMP	2(R4)
TEST17	TEST MEMORY WITH THE DATA CACHE ON				
165744	013704	177570		MOV	#177570,R4
;SWITCH REGISTER TO R4					
;OFFSET ADDR.IN BITS 0-8 OF R4					
165750	042704	177000		BIC	#177000,R4
165754	052704	173000		BIS	#173000,R4
;BITS 0-8 OF SWR CONTAINS STARTING CODE.					
;OF DESIR™ ROM.					
;BITS 9-1 OF SWR = OCTAL UNIT NUMBER.					
;UNIT # RIGHT JUSTIFIED IN R0					
;MAKE SURE C BIT CLEAR					
;EXIT TO BOOT ROM					
;EXTRA WORD					
;IDENTIFIES ROM AS "B0" OR B VERSION REV 0. ECB 12-12					
;CONTAINS CRC-16 WORD FOR LAST 255 WORDS.					
165760	113700	177571		MOVB	#177571,R0
165764	006200			ASR	R0
165766	000241			CLC	
165770	000114			JMP	(R4)
165772	000000			HALT	
165774	041060			.ASCII	"0B"
165776	025055			.WORD	025055
	000001			.END	

616F1.M11

SYMBOL TABLE

BIT8 = 000400
CRCWD = 000000
GRP1 = 000044
JUMP0 165712
RC11CR= 177446
RK06CR= 177440
RS03CR= 172040
R0 =%000000
R4 =%000004
SP =%000006
TST11 165214
TST15 165362
TST3 165070
TST7 165156
TU56CR= 177342

BIT9 = 001000
DIAG = 165564
HSRCR = 177550
MISS = 000014
RESERV= 000340
RL01CR= 174400
RS04CR= 172040
R1 =%000001
R5 =%000005
START 165000
TST12 165234
TST16 165504
TST4 165104
TTCR = 177560
. = 166000

BOOTMI 165720
FIX 165406
INITSW= 173024
MRESER= 173000
RF11CR= 177460
RP03CR= 176714
RX01CR= 177170
R2 =%000002
R6 =%000006
TST1 165046
TST13 165256
TST17 165612
TST5 165116
TU10CR= 172522

CONT 165714
GRP0 = 000030
JUMP 165724
PC =%000007
RK05CR= 177404
RP04CR= 176700
RX02CR= 177170
R3 =%000003
R7 =%000007
TST10 165174
TST14 165310
TST2 165052
TST6 165146
TU16CR= 172440